



720011 1967-1969 Camaro Trunk Hinges

Read and understand these instructions fully before proceeding. If you are not comfortable with installing these hinges, take them to your preferred installation shop. Note: These hinges are not for convertibles or vehicles with altered hinge mounts (tubbed etc.) or for vehicles with aftermarket spoilers, added sound deadener (extra weight) etc. For steel trunk lids only.

A few tips:

Protect your paint surfaces with painters tape if required

Two people make the job much easier

Use anti-seize on all threads to prevent galling

Remove trunk and factory hinge mechanism/torsion rods.

- 1) Install the billet hinges on to the vehicle (threaded hole facing outwards) using the 2 black plastic bushings and shoulder bolt, installing the shoulder bolt from the center of the vehicle. Secure with the washer and lock nut. Repeat for the other side.
- 2) Line up the template provided below with the edge of the torsion rod bracket just under the step of the hinge bracket.
- 3) Drill a 3/8" hole in the position marked to mount the ball stud.
- 4) Attach the ball stud using the washer and lock nut. Ball towards the outside of the vehicle.
- 5) Repeat steps 2-4 for the other side reversing the template.
- 6) Remove the lower ball stud (rod end) from the gas strut by removing the retainer clip. You will not be using this stud as you will be using the stud installed in step 4. Keep the retainer clip!
- 7) Install the gas strut by attaching the body end ball stud to the hinge using a flat washer. Attach the rod end to the ball stud already on the vehicle (installed in step 4) and reinstall the retainer clip.
- 8) Attach the billet hinges loosely to the trunk using the 4 button head cap screws (2 per side) with the countersunk aluminum washers.
- 9) Align trunk as required.

