



If you have ever run wiring through split tubing you know that it can be frustrating. Without this tool, the more wires you have, the harder it is. When you have to add a wire, it can really slow you down.

With this premium wire loom tool, you can add and remove wires quickly and easily. Simply gather the wires you want into the installation tool and then insert the tool and wires into any split tubing or semi-rigid sleeving.

Run the tool through the tubing, smooth it out with your hand and you are finished.



Step 1
Rotate the barrel to line up the slot and insert your wire bundle



Step 2
Rotate the barrel to hide the slot and prevent the bundle from slipping out of the tool



Step 3
Insert the bulge of the tool into your tubing. Make sure that the end of the bundle is properly seated in the tubing

Step 4
Gently slide the tool along the length of the tubing, inserting the wire bundle as you move down the sleeving



Step 5
Run your hand over the length of the installation to smooth out any imperfections.



786000 (Included)
Split Tubing Installation Tool
for bundles up to 1/4"



786010
Split Tubing Installation Tool
for bundles up to 1"



786000 (Included)
Split Tubing Installation Tool
for bundles up to 1/2"



786015
Split Tubing Installation Tool
for bundles up to 1 1/2"



786000 (Included)
Split Tubing Installation Tool
for bundles up to 3/4"